

OPERATING INSTRUCTIONS

Sales and Service 0421 124 018

dj@ecotankaustralia.com.au

LOADING TANK

- 1. Always wear heat resistance gloves, apron and safety glasses
- 2. Open the lid and make sure safety latched is locked.
- 3. Lift the basket onto the hooks.
- 4. Load the basket carefully.
- 5. Lower the basket carefully into solution and close the lid.

UNLOADING TANK

- 1. Always wear heat resistance gloves, apron, and safety glasses.
- 2. Open the lid and make sure safety latched is locked
- 3. Lift the basket onto the hooks
- 4. Remove clean items and rinse thoroughly with hot and cold water
- 5. In case of some items not clean repeat as necessary.
- 6. Lower the basket carefully into solution and close the lid.

CHECK LIST

- 1. Make sure the tank power is ON. (Red indicator light visible from outside).
- 2. Tank Temperature should be 80 85 degrees
- 3. Skim any fats /oils on the surface.
- 4. Check water level and top up as required.
- 5. Any attention required regarding tank call **Ecotank Australia**
- 6. Chemical change required every 30 days cycle.



OPERATING INSTRUCTIONS

Sales and Service 0421 124 018

dj@ecotankaustralia.com.au

FIRST AID MEASURES

In Eye:

Immediately flush with water for at least 15 minutes Get Medical Attention Urgently

On Skin:

Rinse Well with Water Get Medical advice if irritation/burning occurs

Ingested:

Do not Induce Vomiting Rinse Mouth and Drink Water Get Medical Attention Urgently

NOTE

- Always wear: HEAT RESISTANCE GLOVES, APRON AND SAFTY GLASSES.
- Water temperature (80-85 degree) is hot do not use bare hands.
- SDS if required see your Manager.
- We will not be responsible or liable, directly or indirectly of any injuries, loss or damage of any kind as a result of using and servicing Ecotank.

CAUTION HOT

WHY SCRUB WHEN YOU CAN SOAK?